

User Information Sheet

Ronco Item No : 65-014-XX (07, 08, 09, 10)

Brand Name : Vita

Description : 100% Polyester String Knit Glove

with blue band on wrist

Colour : White

Cuff style : Knitwrist, with blue line

Colour coded surging for sizes



Specification

Size :	S	М	L	XL
	7	8	9	10
Item number :	65-014-07	65-014-08	65-014-09	65-014-10
Length (mm):	225	235	250	265
Surging :	Red	Yellow	White	Blue

Packaging : 360P = 12 pairs x 30 bags = 360 pairs per case

Product Features : • 100% Polyester (Minimal Shrinkage when Washed)

- Knitwrist cuff for a snug fit on the wrist
- · Size colour coded surging at the wrist
- Machine washable
- Stretches easily
- Comfortable and breathable
- Ambidextrous

Applications

- : Look for the gloves with the BLUE LINE as a sign of RONCO quality
 - Effective as a glove liner
 - General Labour
 - Assembly
 - Warehouse

Storage & Handling

: Store in original packaging at room temperature under roof away from direct sunlight and moisture. Wash in cool or warm water and hang to dry.

Laundry Instructions

Hand Washing:

- Fill a sink or basin with warm water (40 °C or below) and add soap or mild detergent.
- Soak the gloves in the solution for approximately 5 minutes.
- Rub the gloves together while they are on or off your hands to ensure they are thoroughly cleaned.
- Rinse the gloves thoroughly with warm water, squeeze out any excess water and let the gloves hang
 dry away from any heat source.
- Do not use dryer.

Machine Washing:

- Select the gentle cycle and use cold water (30 °C or below).
- Add a small amount of mild detergent to the washing machine.
- Once the cycle is complete, remove the gloves, squeeze out any excess water and let the gloves hang dry away from any heat source.
- · Do not use dryer.

Notes:

- Please do not use bleach.
- These gloves can be washed up to three times, at a regular level of soiling.

Special Notes

Although reasonable care has been taken in the preparation of this document, no warranties are extended and no liability is assumed. The information is solely provided as a general guideline for product use and care. It is up to end-users to make their own determination as to the suitability of the product for their own intended purpose(s).